



Ediabas v7.7.x settings for ICOM Next, ENET, DCAN...

Used ECC.exe (Ediabas Configuration Center)

Table of Contents:



ENET IFH with ENET-Cable for F-Series and newer, as example for INPA64, Tool64	2
ENET IFH with ICOM Next for F-Series and newer, as example for INPA64, Tool64	3
RPLUS:ICOM_P IFH (DCAN) with ICOM Next for E-Series, as example for INPA, Tool32, NCS	4
RPLUS:MOST_ASYNC IFH (MOST) with ICOM Next + ICOM-B for E-Series for WinKFP	5
STD:OBD IFH with DCAN-USB Cable for E-Series, as example for INPA, Tool32, NCS	6

ENET IFH with ENET-Cable for F-Series and newer, as example for INPA64, Tool64 ...





ENET IFH with ICOM Next for F-Series and newer, as example for INPA64, Tool64 ...

1. Reserve ICOM with ITool Radar
2. If need change Remotehost = „Autodetect“ to IP from your ICOM



RPLUS:ICOM_P IFH (DCAN) with ICOM Next for E-Series, as example for INPA, Tool32, NCS ...



1. Reserve ICOM with ITool Radar
2. Change Remotehost = „YOUR_ICOM_IP“ to IP from your ICOM




RPLUS:MOST_ASYNC IFH (MOST) with ICOM Next + ICOM-B for E-Series for WinKFP

Placeholder

STD:OBD IFH with DCAN-USB Cable for E-Series, as example for INPA, Tool32, NCS ...



Set right USB-Port from your DCAN-USB Cable in C:\EC-APPS\EDIABAS\BIN\obd.ini



Don't forget set Latency in Device Manager to 1ms